







- 1 Starter battery (Left-hand drive and Right-hand drive)
- (5) Additional battery for ECO start/stop (Right-hand drive)
- 2 Additional battery (left-hand drive)
- 3 Additional battery (right-hand drive)
- Additional battery for ECO start/stop (Left-hand drive)

start/stop (Right-hand

Airbag



Gas generator



Seat belt tensioner



Fuel tank



Restraint systems control unit



12 V Battery

Note: Please see our <u>emergency response guide</u> for more information

02.0