







- 1 Starter battery (Left-hand drive and Right-hand drive)
- 2 Additional battery (left-hand drive)
- 3 Additional battery (right-hand drive)
- Additional battery for ECO start/stop (Left-hand drive)

(5) Additional battery for ECO start/stop (Right-hand drive)



Airbag



Gas generator



Seat belt pretensioner



SRS control unit



Low-voltage bat-



Petrol fuel tank

Note: Please see our <u>emergency response guide</u> for more information

03.0