

- 1 Starter battery (Left-hand drive and Right-hand drive)
- 2 Additional battery (left-hand drive)
- 3 Additional battery (right-hand drive)



Airbag



Gas generator




Seat belt pretensioner



SRS control unit



Low-voltage battery



Note: Please see our <u>emergency response guide</u> for more information

03.0