



- ① Starter battery (Left-hand drive and Right-hand drive)
- ② Additional battery (left-hand drive)
- ③ Additional battery (right-hand drive)
- ④ Additional battery for ECO start/stop (Left-hand drive)
- ⑤ Additional battery for ECO start/stop (Right-hand drive)

	Airbag		Gas generator		Seat belt pretensioner		SRS control unit		Low-voltage battery
	Petrol fuel tank								

Note: Please see our [emergency response guide](#) for more information