





- ① Starter battery (Left-hand drive and Right-hand drive)
- ② Additional battery (left-hand drive)
- ③ Additional battery (right-hand drive)
- ④ Additional battery for ECO start/stop (Left-hand drive)
- ⑤ Additional battery for ECO start/stop (Right-hand drive)



Airbag



Gas generator



Seat belt pretensioner



SRS control unit



Low-voltage battery



Petrol fuel tank

Note: Please see our [emergency response guide](#) for more information