





Note: Please see our <u>emergency response guide</u> for more information





Note

Vehicles of this type can additionally be equipped with a 48 V On-board electrical system. The 48 V On-board electrical system is deactivated as soon as at least one airbag has been triggered in the event of a crash. Further details can be found in the rescue manual.





1. Identification / recognition







