



- ① 12 V Battery (12 V On-board electrical system), Left-hand drive
- ② 48 V Battery (48 V On-board electrical system), Left-hand drive
- ③ 12 V Battery (12 V On-board electrical system), Right-hand drive
- ④ 48 V Battery (48 V On-board electrical system), Right-hand drive
- ⑤ 12 V Battery (48 V On-board electrical system)



Note: Please see our [emergency response guide](#) for more information



Note

Vehicles of this type can additionally be equipped with a 48 V On-board electrical system.

The 48 V On-board electrical system is deactivated as soon as at least one airbag has been triggered in the event of a crash.

Further details can be found in the rescue manual.