



① Battery 12 V

② 48 V Battery (48 V On-board electrical system)

③ USA / Canada electrical system



Airbag



Gas generator



Seat belt tensioner



Gas-filled strut



Fuel tank



Restraint systems control unit



12 V / 48 V Battery

Note: Please see our [emergency response guide](#) for more information



**Note**

Vehicles of this type can additionally be equipped with a 48 V On-board electrical system.

The 48 V On-board electrical system is deactivated as soon as at least one airbag has been triggered in the event of a crash.

Further details can be found in the rescue manual.