



① Starter battery

② On-board electrical system battery



Airbag



Seat belt pretensioner



SRS control unit



Gas strut / Pre-loaded spring



High strength zone



Low-voltage battery



Petrol fuel tank

Note: Please see our [emergency response guide](#) for more information