









① Additional battery in engine compartment (up to 31.05.2006)

② Main battery in trunk (vehicles equipped with spare wheel)

③ Main battery in trunk (vehicles not equipped with spare wheel)

-  Zračni jastuk
-  Plinski generator
-  Zatezač sigurnosnog pojasa
-  SRS upravljački uređaj
-  Plinsko-hidraulični podupirač / zategnuta opruga
-  Područje visoke otpornosti
-  Niskonaponski akumulator
-  Benzin spremnik za gorivo

Napomena: Dodatne informacije potražite u našem [Vodiču za spašavanje](#).