



① Battery 12 V

② 48 V Battery (48 V On-board electrical system)



Airbag



Gas generator



Seat belt pretensioner



SRS control unit



Gas strut / Pre-loaded spring



Low-voltage battery (Li-ion battery)



Fuel tank

Note: Please see our [emergency response guide](#) for more information



**Note**

Vehicles of this type can additionally be equipped with a 48 V On-board electrical system.

The 48 V On-board electrical system is deactivated as soon as at least one airbag has been triggered in the event of a crash.

Further details can be found in the rescue manual.