



- ① 12 V Battery (12 V On-board electrical system), Left-hand drive
- ② 48 V Battery (48 V On-board electrical system), Left-hand drive
- ③ 12 V Battery (12 V On-board electrical system), Right-hand drive
- ④ 48 V Battery (48 V On-board electrical system), Right-hand drive
- ⑤ 12 V battery with 48 V electrical system installed

Legend

- Airbag
- Fuel tank
- Gas generator
- Restraint systems control unit
- Seat belt tensioner
- Pedestrian protection
- Gas-filled strut
- 12 V / 48 V Battery

Note

Further information is available in our [Guidelines for Car Rescue Crews](#).



Note

Vehicles of this type can additionally be equipped with a 48 V On-board electrical system.
The 48 V On-board electrical system is deactivated as soon as at least one airbag has been triggered in the event of a crash.
Further details can be found in the rescue manual.