








① Additional battery in engine compartment (up to 31.05.2006)

② Main battery in trunk (vehicles equipped with spare wheel)

③ Main battery in trunk (vehicles not equipped with spare wheel)

-  Airbag
-  Gas generator
-  Seat belt tensioner
-  Gas-filled strut
-  Body reinforcement
-  Fuel tank
-  Restraint systems control unit
-  12 V Battery

Note: Please see our [emergency response guide](#) for more information