



① Additional battery in engine compartment (up to 31.05.2006)

② Main battery in trunk (vehicles equipped with spare wheel)

③ Main battery in trunk (vehicles not equipped with spare wheel)



Airbag



Gas generator



Seat belt tensioner



Gas-filled strut



Body reinforcement



Fuel tank



Restraint systems control unit



12 V Battery

Note: Please see our [emergency response guide](#) for more information