

Low-voltage battery



Petrol fuel tank



Battery pack, High-voltage



High-voltage cable / component



Cable cut





Low voltage device that disconnects high voltage

Note: Please see our [emergency response guide](#) for more information




1. Identification / recognition



3. Disable direct hazards / safety regulations


Deactivation of the high-voltage system

 The high-voltage system is automatically switched off in the event of accidents in which the airbags and seat belt pretensioners trigger.



In all other cases, the high-voltage system should be deactivated as follows:

Alternative high-voltage disconnect



- (1) Pull the release
- (2) Push the release down
- (3) Pull out the switch